

COMMUNICATIONS PHONETIC ALPHABET.

Letter	Word	Pronunciation		Figure Pronunciation	
A	Alpha	AL-fah		1	WUN
B	Bravo	BRAH-voh		2	TOO
C	Charlie	CHAR-lee		3	THUH-REE
D	Delta	DELL-tah		4	FO-WER
E	Echo	ECK-oh		5	FI-YIV
F	Foxtrot	FOKS-trot		6	SIX
G	Golf	GOLF		7	SEVEN
H	Hotel	Hoh-TELL		8	AIT
I	India	IN-dee-ah		9	NINER
J	Juliett	JEW-lee-ETT		0	ZERO
K	Kilo	KEY-loh			
L	Lima	LEE-mah			
M	Mike	MIKE			
N	November	No-VEM-ber			
O	Oscar	OSS-cah			
P	Papa	Pah-PAH			
Q	Quebec	keh-BECK		=====	
R	Romeo	ROW-me-oh			
S	Sierra	See-AIR-rah		RADIO SIGNAL STRENGTHS	
T	Tango	TANG-go		(Said)	(Written)
U	Uniform	YOU-nee-form			
V	Victor	VIK-tah		Loud & Clear	LC
W	Whiskey	WISS-key		Readable	R
X	X-ray	ECKS-ray		Weak Readable	W
Y	Yankee	YANG-key		Unreadable	U
Z	Zulu	ZOO-loo		Nothing Heard	N or NH

TRANSCEIVER FAULT FINDING

- 1 Check Transceiver switched On & Lamps glowing.
- 2 Check Power Leads connected & Fuses intact.
- 3 Check that Battery is not discharged (flat).
- 4 Check that Antenna is connected & erected.
- 5 Check that Volume & Mute/Squelch is correctly adjusted.
- 6 Check that Speaker is connected.
- 7 Ensure correct Frequency or channel is selected.
- 8 Check that Microphone is connected.
- 9 Check that PTT operates the Transmitter & lamp
- 10 Arrange a `radio check' with someone close by.

Rule 3. Always carry out a radio check before leaving Headquarters.